

RTD PRR Task Force: NP04 Data Analysis

Jordi Capó

NP04 TMS Performance Paper

- I am in charge of the elaboration of the paper about the performance of the TMS in NP04;
- Laboratory calibration will cite the recently published paper;
- Some calibration tasks to be performed in-situ about the readout electronics (potentially next week at CERN);
- System's performance and data analysis is nearly completed;
- Has to be released by the end of November;

Abstract



Keywords: Detectors, Liquid Argon, Cryogenics, Photon detection, Optics

1 Contents

2	1 Introduction	2
3	2 ProtoDUNE-HD in the NP04 cryostat	2
4	3 The TMS in NP04	3
5	3.1 The readout electronics of the TMS in NP04	3
6	3.2 The TMS sub-systems	4
7	4 Cryogenics's Operation of the NP04 cryostat	4
8	5 TMS Calibration and Performance	6
9	5.1 Laboratory calibration	6
10	5.2 Readout calibration	7
11	5.3 Pumps-off calibration	9
12	5.4 Performance of the TMS	9
13	6 Temperature Maps as Cryostat Slow-Controls	9
14	6.1 Bulk Temperature	10
15	6.2 Stability of the temperature maps	12
16	6.3 Homogeneity of the temperature maps	14
17	6.4 Sensitivity of temperature maps to changes in operational conditions	16
18	6.4.1 TPC CE	18
19	6.4.2 HV	18
20	6.4.3 PDS	19
21	6.4.4 Recirculation System	20
22	6.4.5 Pump Differential Pressure	20
23	6.4.6 Pump Flow	20



NP04 Operation: Temperature Stability

- NP04 operation is divided into several pieces: normal operation periods in **green** and **blue**;
- Long-term stability quantified to be better than 1 mK;




Temperature Maps: Homogeneity

- Temperature maps are very homogeneous during both normal operation periods;



Temperature Maps: Sensitivity

- Temperature maps are sensitive to the heat released by various detector elements: TPC CE, HV, recirculation system...
- Hawaii measures a bump at ~1m corresponding to the heat released by TPC CE of APA3.
- APA3 sensor at ~1m sees it too, but APA4 does not behave the same way (to be understood);



Some questions about the slow controls

- It would be great to know the **model of the resistors** used to measure the current of the boards, the differences in the TCRs between the 100 and 25 Ohm induce changes based on the room temperature
- I need a precise measurement of the cryostat inner pressure. Right now I have access to PT4910, PT4920, PT0110_REL and PT0110_ABS, which one is the correct? **I have assumed PT0110_REL**
- Is there another way of looking at the **pump differential pressure** other than looking at 4PDT4500?
- Is there another way of looking at **pump flow** other than looking at 4FT4592?
- Are there other **room temperature** sensors other than TT0100?
- There are two **level sensors**: LT0100 and 4LT4921. They both measure liquid levels, one absolute and the other a %. Which one is the most reliable?
- *Are there other key sensors in terms of LAr recirculation control?*

TPC CE


Roger Huang: “For your purposes the bottom row is most relevant. *ltc2991_v0*, *v2*, and *v4* are the power module voltages for the FEMB's power rails, which should all be ~4 V. The difference between those and *v1*, *v3*, *v5* gives a current reading (I forget the exact resistor value), but what you see is typical for when the FEMBs are on. And then there's 4 sets labeled *femb0*, *femb1*, *femb2*, *femb3* for the 4 FEMBs of one WIB.”

WIB 302

Firmware Version: 565250945.00

ZMQ EndPoint:

sw_version:



Power		Sensors											
dc2dc_o1_setpoint	4.00	ad7414_49_temp	27.25	ltc2990_4c_v0	1.22	ltc2990_4e_v0	0.90	ltc2991_48_v0	0.86				
dc2dc_o2_setpoint	4.00	ad7414_4a_temp	27.25	ltc2990_4c_v1	1.21	ltc2990_4e_v1	0.90	ltc2991_48_v1	0.85				
dc2dc_o3_setpoint	4.00	ad7414_4b_temp	27.25	ltc2990_4c_v2	3.30	ltc2990_4e_v2	1.20	ltc2991_48_v2	5.00				
dc2dc_o4_setpoint	4.00			ltc2990_4c_v3	3.30	ltc2990_4e_v3	0.59	ltc2991_48_v3	5.00				
ldo_a0_setpoint	2.50							ltc2991_48_v4	2.50				
ldo_a1_setpoint	2.50							ltc2991_48_v5	2.50				
Cold	█							ltc2991_48_v6	1.80				
Configure	█							ltc2991_48_v7	1.80				
femb0_on	█	femb_bias_ltc2991_v0	5.00	femb_ldo_a0_ltc2991_v0	0.00	femb_ldo_a1_ltc2991_v0	0.00						
femb1_on	█	femb_bias_ltc2991_v1	5.00	femb_ldo_a0_ltc2991_v1	0.00	femb_ldo_a1_ltc2991_v1	0.00	ltc2499_15_temp0	0.49				
femb2_on	█	femb_bias_ltc2991_v2	5.00	femb_ldo_a0_ltc2991_v2	0.00	femb_ldo_a1_ltc2991_v2	0.00	ltc2499_15_temp1	0.50				
femb3_on	█	femb_bias_ltc2991_v3	4.97	femb_ldo_a0_ltc2991_v3	0.00	femb_ldo_a1_ltc2991_v3	0.00	ltc2499_15_temp2	0.49				
stage	0.00	femb_bias_ltc2991_v4	5.00	femb_ldo_a0_ltc2991_v4	0.00	femb_ldo_a1_ltc2991_v4	0.00	ltc2499_15_temp3	0.50				
configure_done	█	femb_bias_ltc2991_v5	5.00	femb_ldo_a0_ltc2991_v5	0.00	femb_ldo_a1_ltc2991_v5	0.00	ltc2499_15_temp4	0.47				
		femb_bias_ltc2991_v6	5.00	femb_ldo_a0_ltc2991_v6	0.00	femb_ldo_a1_ltc2991_v6	0.00	ltc2499_15_temp5	0.51				
		femb_bias_ltc2991_v7	5.00	femb_ldo_a0_ltc2991_v7	0.00	femb_ldo_a1_ltc2991_v7	0.00	ltc2499_15_temp6	0.51				
Timing													
ept_status	58152.00	femb0_dc2dc_ltc2991_v0	3.94	femb1_dc2dc_ltc2991_v0	3.97	femb2_dc2dc_ltc2991_v0	3.96	femb3_dc2dc_ltc2991_v0	3.99				
lol_flg_val	13.00	femb0_dc2dc_ltc2991_v1	3.90	femb1_dc2dc_ltc2991_v1	3.93	femb2_dc2dc_ltc2991_v1	3.92	femb3_dc2dc_ltc2991_v1	3.94				
lol_val	13.00	femb0_dc2dc_ltc2991_v2	3.97	femb1_dc2dc_ltc2991_v2	3.96	femb2_dc2dc_ltc2991_v2	3.98	femb3_dc2dc_ltc2991_v2	3.97				
los_flg_val	0.00	femb0_dc2dc_ltc2991_v3	3.95	femb1_dc2dc_ltc2991_v3	3.94	femb2_dc2dc_ltc2991_v3	3.96	femb3_dc2dc_ltc2991_v3	3.94				
los_val	0.00	femb0_dc2dc_ltc2991_v4	3.93	femb1_dc2dc_ltc2991_v4	3.92	femb2_dc2dc_ltc2991_v4	3.91	femb3_dc2dc_ltc2991_v4	3.92				
		femb0_dc2dc_ltc2991_v5	3.91	femb1_dc2dc_ltc2991_v5	3.90	femb2_dc2dc_ltc2991_v5	3.89	femb3_dc2dc_ltc2991_v5	3.90				
		femb0_dc2dc_ltc2991_v6	0.09	femb1_dc2dc_ltc2991_v6	0.09	femb2_dc2dc_ltc2991_v6	0.09	femb3_dc2dc_ltc2991_v6	0.09				
		femb0_dc2dc_ltc2991_v7	3.89	femb1_dc2dc_ltc2991_v7	3.92	femb2_dc2dc_ltc2991_v7	3.91	femb3_dc2dc_ltc2991_v7	3.94				
poll_period	0.00												

PD-SP Data

- It is very likely that we need to analyse some PD-SP temperature data too;
- The virtual machine is now not working, should I contact Roland (?) in order to have it working again and retrieve the data?
- Are the DCS-ID (long numbers) the same for PD-SP and PD-HD? At least for the cryostat slow controls and temperature sensors (Valencia, Hawaii, Ground Planes, Pipe)